



■ Features :

- True sine wave output (THD<3%)
- High surge power up to 3000W
- U.P.S. mode and energy saving mode (selectable)
- High efficiency up to 91%
- Power ON-OFF switch
- Standby saving mode can be selectable
- Front panel indicator for operation status
- Thermostatically controlled cooling fan
- Protections: Bat. low alarm / Bat. low shutdown / Over voltage / Over temp. / Output short / Input polarity reverse / Overload / AC circuit breaker
- Application : Home appliance, power tools, office and portable equipment, vehicle and yacht ...etc.
- Built-in solar / AC charger
- Optional monitoring software
- 2 years warranty



SPECIFICATION

MODEL	TN-1500-112	TN-1500-124	TN-1500-148	TN-1500-212	TN-1500-224	TN-1500-248
OUTPUT	RATED POWER (Typ.) 1500W					
	MAXIMUM OUTPUT POWER (Typ.) 1725W for 180 sec. / 2250W for 10 sec. / surge power 3000W for 30 cycles					
	AC VOLTAGE			AC VOLTAGE		
	Factory setting set at 110VAC			Factory setting set at 230VAC		
	100 / 110 / 115 / 120VAC selectable by setting button S.W			200 / 220 / 230 / 240VAC selectable by setting button S.W		
	FREQUENCY			FREQUENCY		
	60±0.1Hz 50/60Hz selectable by setting button S.W			50±0.1%Hz 50/60Hz selectable by setting button S.W		
	WAVEFORM True sine wave (THD<3%) at rated input voltage					
AC REGULATION (Typ.) ±3.0%						
TRANSFER TIME <10ms inverter → by pass						
SAVING MODE (Typ.) Load ≤5W will be changed to standby mode						
FRONT PANEL INDICATOR Battery voltage level, output load level, saving mode, fault and operation status						
INPUT	BAT. VOLTAGE		BAT. VOLTAGE		BAT. VOLTAGE	
	12V		24V		48V	
	VOLTAGE RANGE (Typ.) ^{Note.1}		VOLTAGE RANGE (Typ.) ^{Note.1}		VOLTAGE RANGE (Typ.) ^{Note.1}	
	10.5 ~ 15VDC		21 ~ 30VDC		42 ~ 60VDC	
	DC CURRENT (Typ.) ^{Note.5}		DC CURRENT (Typ.) ^{Note.5}		DC CURRENT (Typ.) ^{Note.5}	
	150A		75A		37.5A	
NO LOAD DISSIPATION ≤18W @ standby saving mode						
OFF MODE CURRENT DRAW ≤1mA						
EFFICIENCY (Typ.) ^{Note.2}		EFFICIENCY (Typ.) ^{Note.2}		EFFICIENCY (Typ.) ^{Note.2}		
87%		89%		90%		
BATTERY TYPES Open & sealed Lead Acid						
BATTERY INPUT PROTECTION	FUSE		FUSE		FUSE	
	40A*5		30A*3		30A*2	
	BAT. LOW ALARM		BAT. LOW ALARM		BAT. LOW ALARM	
	11.3±4%		22.5±4%		45±4%	
BAT. LOW SHUTDOWN		BAT. LOW SHUTDOWN		BAT. LOW SHUTDOWN		
10.5±4%		21±4%		42±4%		
REVERSE POLARITY By internal fuse open						
OUTPUT PROTECTION	OVER TEMPERATURE		OVER TEMPERATURE		OVER TEMPERATURE	
	82°C ± 5°C		82°C ± 5°C		96°C ± 5°C	
	Protection type : Shut down o/p voltage, re-power on to recover ; by internal RTH3 detect on heatsink of power transistor					
	OUTPUT SHORT Protection type : Shut down o/p voltage, re-power on to recover					
	OVER LOAD (Typ.) 105 ~ 115% load for 180 sec., 115% ~ 150% load for 10 sec.					
Protection type : Shut down o/p voltage, re-power on to recover						
CIRCUIT BREAKER				CIRCUIT BREAKER		
20A				10A		
GFCI PROTECTION Optional (Only type F)						
None						
ENVIRONMENT	WORKING TEMP. ^{Note.3} 0 ~ +40°C @ 100% load ; 60°C @ 50% load					
	WORKING HUMIDITY 20% ~ 90% RH non-condensing					
	STORAGE TEMP., HUMIDITY -30 ~ +70°C / -22 ~ +158°F, 10 ~ 95% RH					
	VIBRATION 10 ~ 500Hz, 3G 10min./1cycle, 60min. each along X, Y, Z axes					
SAFETY & EMC	SAFETY STANDARDS UL458 (only for "GFCI" receptacle-Type F) None					
	LVD			LVD		
	None			EN60950-1		
	WITHSTAND VOLTAGE Bat I/P - AC I/P:3.0KVAC Bat I/P - AC O/P:3.0KVAC AC O/P - FG:1.5KVAC					
	EMI CONDUCTION&RADIATION			EMI CONDUCTION&RADIATION		
Compliance to FCC class A			Compliance to EN55022 class B, 72/ 245/ CEE, 95/ 54/ CE, E-Mark			
EMS IMMUNITY						
Compliance to EN61000-4-2,3,4,5,6,8,11 ENV50204						
AC CHARGER	CHARGE CURRENT (Typ.)		CHARGE CURRENT (Typ.)		CHARGE CURRENT (Typ.)	
	5.5A		2.7A		1.35A	
	CHARGE VOLTAGE		CHARGE VOLTAGE		CHARGE VOLTAGE	
14.3V±4%		28.5V±4%		57V±4%		
SOLAR CHARGER	MAX OPEN CIRCUIT VOLTAGE		MAX OPEN CIRCUIT VOLTAGE		MAX OPEN CIRCUIT VOLTAGE	
	25V		45V		75V	
	CHARGE CURRENT (max.)		CHARGE CURRENT (max.)		CHARGE CURRENT (max.)	
30A		30A		30A		
CHARGE VOLTAGE		CHARGE VOLTAGE		CHARGE VOLTAGE		
14.3V±4%		28.5V±4%		57V±4%		
OTHERS	CONTROL WIRING RJ11 -RS232 (Option)					
	DIMENSION 420*220*88mm (L*W*H)					
	PACKING 6.85Kg; 2pcs/14.7Kg/1.61CUFT					
NOTE	<p>1. Output derating capacity referenced by curve 1.</p> <p>2. Efficiency is tested by 1000W, linear load at 13V, 26V, 52V input voltage.</p> <p>3. Output derating capacity referenced by curve 2.</p> <p>4. All parameters not specified above are measured at rated load, 25°C of ambient temperature.</p> <p>5. DC current is tested by 1500W, linear load at 13V, 26V, 52V input voltage.</p>					

■ Instructions for TN-1500 monitoring software

1. Installation of TN-1500 unit and PC




Figure 1

2. Explanation of Monitoring Manu

2.1 Main Page




Figure 2

1. Setting: Adjustment for output voltage, charging related voltage, frequency, and operation mode. Please refer to Figure 3 for details.
2. Statistics: Calculate for the percentage of operating period for each operation mode. Please refer to Figure 4 for details.
3. R.C. Power off: Power can be turned ON or OFF at the remote location.
4. Pause: Stop refreshing the page of monitoring software.
5. Status of unit: Indicating current operating status of TN-1500.
6. Signals that display current condition of the unit.

2.2 Setting Page




Figure 3

1. User can adjust the settings based on the characteristics of batteries been used: Equalization Voltage, Floating Voltage, Alarm Voltage, and Shut-down Voltage. UPS Mode / Energy Saving Mode selection and AC output voltage and frequency can also be set in this page.
2. Read: Read current settings of the unit.
3. Write: Write the revised setting into the unit.
4. Load: Load in factory default settings.

2.3 Statistic Page





Figure 4

1. Start Date: Date that installing the monitoring software.
2. Reset Date: Date that resetting the statistics. The Start Date will not be influenced by resetting the statistics or turning off the unit.
3. Inverter time rate: Operating period of "Inverter Mode" represents how many percent of the whole operating period.
4. Bypass time rate: Operating period of "Bypass Mode" (energy provides directly by the utility) represents how many percent of the whole operating period.
5. Shut down rate: Percentage of time period that the unit is under the condition of shut down.
*** Inverter time rate + Bypass time rate + Shut down rate = 100%**
6. Solar time rate: Percentage of time period that the solar charger is functioning after turning on the TN-1500 unit.
7. Loading average: Average loading after turning on the TN-1500 unit.



1500W True Sine Wave DC-AC Inverter with Solar Charger

TN-1500 series






■ AC Output Receptacles (optional)


Receptacle type						
Country	USA	EUROPE	AUSTRALIA	U.K	JAPAN	GFCI
Certificate						

■ Mechanical Specification

Unit:mm



Type-A



Type-B